




PercuttiBeauty®

DEPILADOR ELÉCTRICO

Instrucciones de seguridad:

Para garantizar el funcionamiento adecuado y seguro de este dispositivo, lea cuidadosamente el manual de instrucciones y guárdelo para futuras consultas.

⚠ ADVERTENCIA

- No utilice el dispositivo en las siguientes condiciones: personas con alergias; personas con heridas abiertas, piel agrietada o hinchada en el área de uso; personas con otras enfermedades graves de la piel, etc.
- Siempre revise el cabezal de la cuchilla del dispositivo antes de usarlo.
- No utilice el dispositivo si no funciona correctamente o parece dañado o roto para evitar lesiones.
- Suspenda su uso inmediatamente y consulte a un médico si presenta alguna anomalía o se detecta un mal funcionamiento durante el uso.
- Suspenda su uso inmediatamente y consulte a un médico si tiene problemas en la piel después de usar el dispositivo.
- No intente modificar ni desmontar (excepto piezas desmontables) o repare el dispositivo usted mismo para evitar accidentes.

⚠ PRECAUCIÓN

- Limpie periódicamente el dispositivo para prolongar su vida útil.
- Este dispositivo no es un juguete. Mantener fuera del alcance de los niños.
- Este dispositivo funciona con pilas. Si no utiliza el dispositivo para mucho tiempo, retire las pilas.

Especificaciones:

- Nombre: Electric Shaver
- Modelo N°.: 1659
- Power: 3V ---
- Tipo de Batería: AAAx2 (No incluida)
- Estándar ejecutivo: Q/XM 1008-2020

Descripción del Producto (Imagen 1):

- ① Cubierta protectora de la hoja
- ② Cuchilla de hoja de malla
- ③ Cuchilla de afeitar para el cabello
- ④ Botón de liberación del cabezal
- ⑤ Interruptor de alimentación
- ⑥ Tapa de la batería
- ⑦ Cepillo de limpieza




Imagen 1

Instrucciones de uso:

Lea atentamente las instrucciones antes de utilizar el dispositivo para asegurar un funcionamiento adecuado.

Instalar las baterías.

1. Asegúrese de que el dispositivo esté apagado. Agarre el cuerpo del dispositivo con una mano y darle la vuelta (evite encender el dispositivo deslizando accidentalmente el botón del interruptor). Con la otra mano, sostenga la tapa de la batería. (Imagen 2)
2. Sostenga el dispositivo firmemente y mueva la cubierta protectora hasta que el espacio se separe del dispositivo. (Imagen 3)
3. Inserte 2 pilas AAA alineando los polos +/- . Pon la tapa de la batería de nuevo en.

Duración de la batería: aproximadamente 1,5 horas.




Imagen 2




Imagen 3

Quitar/instalar el cabezal de afeitado

- Para quitar el cabezal de afeitado, presione los botones de liberación del cabezal de afeitado a ambos lados del dispositivo y tire del cabezal de afeitado hacia arriba. (Imagen 4)
- Para instalar el cabezal de afeitado, mantenga presionado el botón de liberación del cabezal de afeitado. botones en ambos lados del cuerpo del dispositivo e inserte lentamente la afeitadora cabeza hasta que bloquee la posición. (Imagen 5)




Imagen 4




Imagen 5

Usando el dispositivo

1. Retire la tapa protectora y deslice el interruptor de encendido hacia arriba para encienda el dispositivo. (Imagen 6)
2. Coloque ligeramente el cabezal de la cuchilla sobre la piel en un ángulo de 90 grados y mueva la afeitadora lentamente en dirección contraria al crecimiento del vello. (Imagen 7)




Imagen 6



Imagen 7

3. Al afeitarse el vello corporal, mueva el cabezal de la cuchilla hacia arriba desde el tobillo hasta el muslo (Imagen 8), y desde el interior hacia el exterior del brazo. (Imagen 9)
4. El vello de las axilas puede crecer en diferentes direcciones. Al recortar este área, asegúrese de levantar el brazo para estirar la piel. Si es necesario, puedes darle un estiramiento adicional a la piel usando tu dedos. Comience a recortar desde el centro hacia afuera en contra de la dirección de crecimiento del cabello. Si es necesario, afeítese en diferentes direcciones para mejorar resultados. (Imagen 10)
5. Después de su uso, deslice el interruptor de encendido hacia abajo para apagar el dispositivo.



Imagen 8



Imagen 9



Imagen 10

Descripción del cabezal de la hoja

1. Cuchilla de afeitar de malla
- Esta cuchilla es adecuada para recortar pelos más gruesos y más cortos. (incluida la barba incipiente de los hombros). La hoja de afeitar es flexible y requiere una presión adecuada durante el uso.
2. Hair Shaving Blade
- This blade is suitable for trimming long and shorter hair (except for thick shorter hair). The blade rounded tips are designed not to scratch the skin, providing a safe trimming experience.

Limpieza y mantenimiento:

1. El dispositivo debe estar apagado antes de comenzar a limpiarlo.
2. No sumerja el dispositivo en agua. Piezas/accesorios desmontables se puede limpiar por separado.
3. La superficie del dispositivo se puede lavar con agua. Utilice un paño limpio y seco para secarlo.
4. No utilice ningún lubricante, detergente, agentes de pulido o ambientadores en este dispositivo.

5. El cabezal de cuchilla extraíble debe limpiarse con un limpiador cepillar y luego enjuagar con agua.
6. No utilice toallas, toallas de papel ni esponjas de alambre para limpiar el cabezal de afeitado.

Garantía y soporte:

Consejos ecológicos

Las baterías contienen sustancias nocivas para nuestro medio ambiente, por favor no deseche las baterías con la basura doméstica normal, en su lugar, entréguelos en un punto de reciclaje oficial.

Troubleshooting

Problema	Posible Causa	Solución
Desliza el interruptor y el dispositivo no funciona	Las baterías estan mal insertadas	Insertar las pilas correctamente según lo guiado.
	The batteries are running low or is out of power.	Replace the batteries as guided.
El cabezal de afeitar esta suelto	El cabezal de afeitar no fue instalado correctamente.	Apague el dispositivo e instale el cabezal correctamente
Otros problemas		Contacte con su vendedor local

Nota: Si el dispositivo aún no funciona correctamente después de usar las soluciones anteriores, deje de usar el dispositivo y póngase en contacto con su distribuidor local.

Servicio postventa

Visite nuestro sitio web www.percutti.com o comuníquese con nuestro equipo de servicio al cliente si lo necesita para conocer nuestros productos o si necesitas cualquier información.

4. Do not use any lubricant, detergent, polishing agents or air freshener on this device.
5. The removable blade head should be cleaned with the cleaning brush and then rinsed with water.
6. Do not use towels, paper towels, and wire ball sponge to clean the Shaver Head.

Warranty & Support:

Eco-Friendly Tips

Batteries contain substances harmful to our environment, please do not dispose of the batteries with the normal household waste, instead, hand them over at an official recycling point.

Troubleshooting

Problem	Possible Cause	Solution
Slide the power switch and the device doesn't work.	The batteries were inserted incorrectly.	Insert the batteries correctly as guided.
	The batteries are running low or out of power.	Replace the batteries as guided.
The shaver head falls off.	The shaver head was not installed correctly.	Turn off the device and install the shaver head correctly as guided.
Other problems.		Contact your local retailer.

Note: If the device still does not work properly after using the above solutions, please stop using the device and contact your local retailer.

After-Sales Service

Please visit our website www.percutti.com or contact our customer service team if you need to learn about our products or if you need any information. You can also contact an affiliate dealer in your country.

Nos complace informarle que el producto adquirido: está cubierto por una garantía de dos años a partir de la fecha de compra, según lo estipulado por la normativa Directiva (UE) 2019/7711. Y 3 años en España: Real Decreto Legislativo 1/2007. Art 120 BOE-A-2007-20555 Real Decreto Legislativo 1/2007, de 16 de noviembre.


Esta garantía cubre cualquier defecto de fabricación o fallo funcional que pueda ocurrir durante el uso normal del producto. En caso de que se produzca un fallo, Marketeam Options S.L. se compromete a reparar o reemplazar el producto sin coste alguno para usted.

Por favor, tenga en cuenta que esta garantía no cubre los daños causados por el uso indebido del producto, la falta de mantenimiento, los accidentes, las modificaciones o las reparaciones realizadas por personas no autorizadas por Marketeam Options S.L. Para hacer uso de la garantía, por favor, póngase en contacto con nuestro servicio de atención al cliente a través del email: contacto@marketeam.es con su prueba o ticket de compra de compra.

Agradecemos su confianza en nuestros productos y nos esforzamos por ofrecerle la mejor calidad y servicio."

PercuttiBeauty®

Importado y distribuido por / Imported and distributed by:
MARKETTEAM OPTIONS S.L. CIF: B2882473
C/ IGARSA 13C. Pol. IGARSA 28860
PARACUELLOS DE JARAMA, MADRID (SPAIN)



PercuttiBeauty®

ELECTRIC SHAVER

Safety Instructions:

To ensure proper operation of this appliance, please read this instruction manual carefully before using the appliance and keep it for further reference.

⚠ WARNING

- Do not use the device under the following conditions: persons with allergies; persons with open wounds, chapped or swollen skin in the area of use; persons with other severe skin diseases, etc.
- Always check the device's body and blade head before you use it. Do not use the device if it is not working properly, appears damaged or broken to prevent injuries.
- Immediately discontinue use and consult a doctor if any abnormality or malfunction is detected during use.
- Immediately discontinue use and consult a doctor if skin problems appear after using the device.
- Do not attempt to modify, disassemble (except detachable parts) or repair the device by yourself to prevent accidents.

⚠ CAUTION


- Regularly clean the device to extend its lifetime.
- This device is not a toy. Keep out of children's reach.
- This device is battery-operated. If you do not use the device for a long time, remove the batteries.

Specifications:

- Name: Electric Shaver
- Model No.: 1659
- Power: 3V ---
- Type of Battery: AAA x 2 (Not Included)
- Executive Standard: Q/XM 1008-2020

Product Description (Picture 1):

- ① Blade Protective Cover
- ② Mesh Shaving Blade
- ③ Hair Shaving Blade
- ④ Shaver Head Release Button
- ⑤ Power Switch
- ⑥ Battery Cover
- ⑦ Cleaning Brush




Picture 1

Using Instructions:


Please read the instructions carefully before using the device to ensure proper operation.

Install the Batteries

1. Make sure that the device is turned off. Grasp the device body with one hand and turn it upside down (avoid turning on the device by sliding the switch button accidentally). With the other hand, hold the battery cover. (Picture 2)
 2. Hold the device firmly and wiggle the protective cover until the gap is big enough to pull it until it separates from the device. (Picture 3)
 3. Insert 2 AAA batteries aligning the +/- poles. Put the battery cover back on.
- Battery life: approximately 1.5 hours.




Picture 2




Picture 3

Remove/Install the Shaver Head

1. To remove the shaver head, press the shaver head release buttons on both sides of the device and pull the shaver head upwards. (Picture 4)
2. To install the shaver head, press and hold the shaver head release buttons on both sides of the device body and slowly insert the shaver head until it locks the position. (Picture 5)




Picture 4



Picture 5

Using the Device

1. Remove the protective cap and slide the power switch upwards to turn the device on. (Picture 6)
2. Lightly place the blade head on the skin at a 90-degree angle and move the shaver slowly against the direction of hair growth. (Picture 7)



Picture 6



Picture 7

3. When shaving body hair, move the blade head upwards from the ankle to the thigh (picture 8), and from the inside to the outside area of the arm. (Picture 9)
4. The armpit hair may grow in different directions. When trimming this area, make sure you hold your arm up to stretch your skin. If you find it necessary, you can give an extra stretch to the skin by using your fingers. Start trimming from the center outwards against the direction of hair growth. If necessary, shave in different directions for better results. (Picture 10)



Picture 8



Picture 9



Picture 10

5. After use, slide the Power Switch downwards to turn the device off.

Blade Head Description

1. Mesh Shaving Blade
- This blade is suitable for trimming thicker and shorter hairs (including men's stubble beards). The shaving blade is flexible and requires proper pressure during use to remove hair effectively.
2. Hair Shaving Blade
- This blade is suitable for trimming long and shorter hair (except for thick shorter hair). The blade rounded tips are designed not to scratch the skin, providing a safe trimming experience.

Cleaning & Maintenance:

1. Make sure the device is turned off before you start cleaning it.
2. Do not immerse the device in water. Detachable parts/ accessories can be cleaned separately.
3. The device's surface can be washed with water. Use a clean, dry cloth to dry it.

We are pleased to inform you that the purchased product: is covered by a two-year warranty from the date of purchase, as stipulated by Directive (EU) 2019/7711. And 3 years in Spain: Royal Legislative Decree 1/2007. Art 120 BOE-A-2007-20555 Royal Legislative Decree 1/2007, of 16 November.

This warranty covers any manufacturing defect or functional failure that may occur during normal use of the product. In the event of a fault occurring, Marketeam Options S.L. undertakes to repair or replace the product at no cost to you.

Please note that this warranty does not cover damage caused by improper use of the product, lack of maintenance, accidents, modifications or repairs carried out by persons not authorised by Marketeam Options S.L. To make use of the warranty, please contact our customer service via email: contacto@marketeam.es with your proof of purchase or purchase receipt.

We appreciate your confidence in our products and we strive to provide you with the best quality and service.

PercuttiBeauty®

Importado y distribuido por / Imported and distributed by:
MARKETTEAM OPTIONS S.L. CIF: B2882473
C/ IGARSA 13C. Pol. IGARSA 28860
PARACUELLOS DE JARAMA, MADRID (SPAIN)